

Service instruction for exchange a faulty adapter:

1. Remove the power plug from the socket
2. Remove the hose adapter from the pump head
3. Take off the pump head from the container and turn it over
4. At the bottom side of the pump head there are 4 Torx-screws they you must remove
5. Now remove the cover hood with the safety adapter
6. You will get out the adapter when you cut off the red locking lever with a side cutter
7. Put the small spring in the new red locking lever and set it in the bottom side of the pump head
8. Set the cover hood **without** the safety adapter on the container
9. Put the 4 Torx-screws back into place and tighten them
10. Ready!

In order to prevent a renewed breaking the new safety adapter, we recommended to take care the ball joint with commercial Vaseline or our especially care spray article number 4001000.

Assembly the Locking lever



Put the locking lever together with the spring into place. See the picture on the side.

The locking lever must be installed that he will be pressed from the spring against the plastic peg.

Assembly the cover hood with the 4 screws and tighten them. Follow the same screwing technique as the self priming system.