

Safety Adapter Prof3 and 3e, Prof4+ and 4+e

Control lever in rough running

The sealing rings from the shut-off balls are greased in production process with Vaseline. Upon this case through the permanent water flow the lubricate fade away and the sealing rings are losing his sliding properties.

With each cleaning please lubricate the sealing rings again.



Use only water neutral **EHEIM** Aquaristic-Carespray (Art.-No. 4001000) or commercial Vaseline. No mineral or cosmetic oils or fats.
Harmful to animals and plants.

	<p><u>Using with Vaseline</u></p> <ul style="list-style-type: none">• Close the Safety adapter with the Control lever, the shut-off balls are visible.• Cotton bud brush with Vaseline and lubricate both white shut-off balls.• Move the Control lever 2 or 3 times till he is easy of motion. If it needs repeat the points as we mentioned before.
	<p><u>Using with <i>EHEIM</i>-Aquaristic Carespray</u></p> <ul style="list-style-type: none">• Close the Safety adapter with the Control lever, the shut-off balls are visible.• Spray both white shut off balls.• Move the Control lever 2 or 3 times till he is easy of motion. If it needs repeat the points as we mentioned before..